

Getting Started with HP ArcSight Management Center Appliance

The HP ArcSight Management Center Appliance package includes detailed rack installation instructions, which you can use to rack-mount your appliance. After rack-mounting, you can set up your Appliance for first use.

This document explains how to configure an IP address on the Appliance, install a license file, and connect to it the first time.

Follow these basic steps to install and start using your Appliance:

- 1 Prepare to Install the ArcSight Management Center Appliance
- 2 Install the ArcSight Management Center Appliance
- 3 Configure a New IP Address
- 4 Accept the End User License Agreement and Log In
- 5 Initialize the ArcSight Management Center Appliance
- 6 Get the Management Appliance Documentation
- 7 Set Up the Management Appliance for Remote Access

Prepare to Install the ArcSight Management Center Appliance

Prior to installation of the ArcSight Management Center Appliance, do each of the following:

- 1 Redeem your Management Appliance license key by following the instructions in the enclosed "Hewlett-Packard Entitlement Certificate" document. You will need this key to access Management Appliance functionality.
- 2 Apply for an account on Protect 724 (<http://protect724.hp.com>), the ArcSight user community. You will need this account to access product documentation and other community-based resources for Management Appliance.

Install the ArcSight Management Center Appliance

To install the ArcSight Management Center Appliance:

1. Unpack the appliance and its accompanying accessories.



Read carefully through the instructions, cautions, and warnings that are included with the appliance shipment. Failing to do so can result in bodily injury or appliance malfunction.

2. Follow the rack installation instructions to securely mount it.
3. Make the rear panel connections.
4. Power on the appliance.

Configure a New IP Address

ArcSight Management Center Appliance ships with the default IP address `192.168.35.35` (subnet mask `255.255.255.0`) on Eth0. To begin setting up your appliance, use the ArcSight Management Center Appliance Command Line Interface (CLI) to configure a new IP address.

To run a command in the CLI, type it at the prompt and then press **Enter**.

To set up a new IP address for Management Appliance:

1. Select one of the following methods to connect to the Management Appliance CLI:
 - ◆ Log into iLO and launch the remote console feature. For more information, see [“Set Up the Management Appliance for Remote Access” on page 4](#).
 - ◆ Connect a keyboard and monitor to the ports on the rear panel of the Appliance.
 - ◆ Connect a terminal to the serial port on the Appliance using a null modem cable with DB-9 connector. The serial port requires a standard VT100-compatible terminal: 9600 bps, 8-bits, no parity, 1 stop bit (8N1), no flow control.
2. In the CLI, enter the following default credentials to log in as the administrator:
Login: `admin`
Password: `password`
3. Enter the IP address in one of the following formats:
 - ◆ `set ip eth0 <ip>/<prefix>`
(For example, `set ip eth0 192.0.2.5/24`)
 - ◆ `set ip eth0 <ip> <subnetmask>`
(For example, `set ip eth0 192.0.2.5 255.255.255.0`)
4. Enter `set defaultgw <ip>`, replacing `<ip>` with your default gateway IP address.
5. Enter `set hostname <domain_name>.<company.com>`, replacing `mydomain.mycompany.com` with the fully-qualified domain name (FQDN) of the desired host.

-
- 6 Enter `set dns <search_domain_name1>, <search_domain_name2>, ... <nameserver1> <nameserver2>`, replacing each `<search_domain_nameN>` with a search domain, and each `<nameserverN>` with the IP address of a name server. (For example, `set dns mydomain1.mycompany.com, mydomain2.mycompany.com 192.0.2.1 192.0.2.2`).
 - 7 Enter `set ntp <ntp_server> <ntp_server> <ntp_server>`, replacing `<ntp_server>` with the NTP server you want to use to set the time. (For example, `Management Appliance> set ntp time.nist.gov`)
 - 8 To confirm that the settings are correct for your environment, enter `show config`.

For more information on the Command Line Interface, refer to the *HP ArcSight Management Center Appliance Administrator's Guide*, or enter `help` at the prompt for a list of available commands.

Accept the End User License Agreement and Log In

The first time you connect to the ArcSight Management Center Appliance through a browser, you are directed to the End User License Agreement. Before you can log in and initialize the appliance, you must review and accept the license agreement.

To accept the license agreement and start initializing ArcSight Management Center Appliance:

- 1 Use the following URL to connect to ArcSight Management Center Appliance through a supported browser: `https://<IP address>`, where `<IP address>` is the new IP address you just configured.

Scroll down to the bottom of the screen to review the license. Mark the "I accept the terms of the License Agreement" check box and click **Accept**.

The Login screen is displayed.

- 2 Use the following default credentials to log in as the administrator:

Username: `admin`

Password: `password`

For security reasons, be sure to change the default credentials as soon as possible after connecting to Appliance for the first time. Refer to the *HP ArcSight Management Center Appliance Administrator's Guide* for instructions.

Initialize the ArcSight Management Center Appliance

After logging in for the first time, the ArcSight Management Center Appliance Configuration page appears. In the **License** field, you can browse for and upload your current license.

Once the license is successfully loaded, click **Save** to save it. Optionally, you may also set your date and time settings. Once these steps are completed, your Appliance is ready for use.

For instructions on how to operate the ArcSight Management Center Appliance and configure it to suit your needs, see the *HP ArcSight ArcSight Management Center Administrator's Guide*. You should also refer to the release notes for any late-breaking information.

Get the Management Appliance Documentation

The Release Notes and HP ArcSight Management Center Appliance Administrator's Guide for your Appliance are available for download from the ArcSight Protect 724 Community at <https://protect724.hp.com>.

Online Help for ArcSight Management Center Appliance is available through the user interface (UI). The help provides the same information contained in the Administrator's Guide in a contextual format. To access the help, click the help icon in the top right corner of any ArcSight Management Center Appliance UI page.

Set Up the Management Appliance for Remote Access

HP ArcSight strongly recommends setting up and configuring your appliance for out-of-band remote access. Doing so ensures that you (as well as HP Customer Support, with your permission and assistance) can remotely access your appliance's console for troubleshooting, maintenance, and power control.

All ArcSight Management Center Appliances are equipped with an HP ProLiant Integrated Lights-Out (iLO) Advanced remote management card. Follow the directions in the *HP ProLiant Integrated Lights-Out User Guide* to set up your appliance for remote access. The guide is available at <http://www.hp.com/go/iLO>.

Contact Information

Phone	A list of phone numbers is available on the HP ArcSight Technical Support page: http://www8.hp.com/us/en/software-solutions/software.html?compURI=1345981#.URitMaVwpWI .
Support Web Site	http://support.openview.hp.com
Protect 724 Community	https://protect724.arcsight.com

Copyright © 2014 Hewlett-Packard Development Company, L.P.

Confidential computer software. Valid license from HP required for possession, use or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Follow this link to see a complete statement of copyrights and acknowledgements:
<http://www.hpenterprisesecurity.com/copyright>

